

## #0022 Transport data in the VDA 4913



## Additional specifications for the FTL process

In general, the description VDA 4913 applies. The deviations for the transport management (FTL process) are described below. Please coordinate this number in advance with the forwarder (for which truck/transport which number is assigned).

Record type	Pos.	Position	Data element	Example of entry / Code
SA 712	13	62-75	Transport partner number	12345678
SA 712	14	76-77	Means of transport code	02
SA 712	15	78-102	Means of transport number	XXXX0001 (Bordero-number)
SA 712	16	103	Means of transport information code	2
SA 712	17	104-111	Means of transport information	BB D 123

## Sample view in IBL-DQM:



		,	
	Transport partner number	SA712 Pos. 13	12345678
	Carrier	SA712 Pos. 05	TEST
	Means of transport code	SA712 Pos. 14	Bordero number
	Means of transport number	SA712 Pos. 15	XXXX0001
	Means of transport information code	SA712 Pos. 16	Number plate
	Means of transport information	SA712 Pos. 17	BB D 123

## Example from the entry in VDA 4913:

+1+2	-+3+4	+5+6	+9	+0+	1+2+	3+
71103100067081234567860	72960730230704					
7120308006716080Name Sp	editeur23070409170000	622000012905 0005 <mark>1</mark>	2345678 02xxxx0001	2xx-xxx	23070400000003	
7130308246486230704953	00A0B 5500000000	XXX	ABCD	St. 15		
71403A0000000000	428969001	000000000100	000ST0000000000000 000 001	S	X	
71602						
715035010	08-091000	0000000000001	0010000000000000808923352	1200100001521	MMK	

- Depending on the transport concept, the border and forwarding number must be transmitted in the shipping notification.
- It must be ensured that the transmission of the shipping notification for each individual shipment can take place both with and without bordero number.
- A transmission of non-coordinated bordero numbers is not permitted, since these lead to an incorrect EDI processing.

Detailed information can be found in the RDT manual chapter 4: <u>Trefferliste (daimler.com)</u>